

CI80A Parts List

- 1 Cast Control Knob
- 2 Cast Control Rubber Washer
- 3 Cast Control Brass Washer
- 4 Retaining Clip
- 5 Ball Bearing
- 6 O-Ring
- 7 Screw
- 8 Bait Clicker Button
- 9 Bait Clicker Button Washer
- 10 Left Side Plate
- 11 Left Gear Plate
- 12 Location Pillar
- 13 Pawl Washer
- 14 E-Ring
- 15 Pawl
- 16 Pawl Spring
- 17 Tension Spring
- 18 Level Wind Gear
- 19 Washer
- 20 Main Body Assembly
- 21 Worm Shaft
- 22 Line Guard
- 23 Line Guide
- 24 Line Guide Pawl
- 25 Washer
- 26 Line Guide Pawl Cap
- 27 Bushing
- 28 C-Clip
- 29 Level Wind Pinion Gear
- 30 Spool Assembly
- 31 Right Gear Plate
- 32 Thumb Button
- 33 Latch Spring
- 34 Allocated Spring
- 35 Yoke
- 36 Yoke Spring
- 37 Washer
- 38 Bushing
- 39 Crankshaft
- 40 Clutch Disc
- 41 Bigger Washer
- 42 Drag Friction Disc

- 43 Main Gear
- 44 Anti-Rotate Disc
- 45 Drag Spring Washer
- 46 Smaller Washer
- 47 Anti-Reverse Ball Bearing
- 48 Pinion Gear
- 49 Right Side Plate
- 50 Star Drag Handle
- 51 Handle Spring Washer
- 52 Handle
- 53 Handle Nut
- 54 Latch Keeper