

Ming Yang Reels

Model CZH 30

Note: When ordering parts, please add CZH30- to the corresponding part number as identified by diagram.

Part No.	Description	Part No.	Description
CZH30-1	Label	CZH30-30	Drag Friction Disc
CZH30-2	Screw	CZH30-31	Main Gear
CZH30-3	Bait Clicker Button	CZH30-32	Drag Spring Washer
CZH30-4	Bait Clicker Spring	CZH30-33	Bushing
CZH30-5	Left Side Plate	CZH30-34	Anti-Reverse Ball Bearing
CZH30-6	Left Gear Plate	CZH30-35	Pinion Gear
CZH30-7	Ball bearing	CZH30-36	Right Side Plate
CZH30-8	Level Wind Gear	CZH30-37	Ball Bearing
CZH30-9	E-Ring	CZH30-38	O-Ring
CZH30-10	Main Body Assembly	CZH30-39	Retaining Clip
CZH30-11	Level Wind Pinion Gear	CZH30-40	Cast Control Brass Washer
CZH30-12	Spool Assembly	CZH30-41	Cast Control Rubber Washer
CZH30-13	Worm Shaft	CZH30-42	Cast Control Knob
CZH30-14	Line Guard	CZH30-43	Star Drag Handle
CZH30-15	Line Guide	CZH30-44	Handle Spring Washer
CZH30-16	Bushing	CZH30-45	Handle
CZH30-17	Washer	CZH30-46	Handle Nut
CZH30-18	Line Guide Pawl	CZH30-47	Latch Keeper
CZH30-19	Washer		
CZH30-20	Line Guide Pawl Cap		
CZH30-21	Right Gear Plate		
CZH30-22	Thumb Button		
CZH30-23	Latch Spring		
CZH30-24	Yoke		
CZH30-25	Yoke Spring		
CZH30-26	Crankshaft		
CZH30-27	Clutch Disc		
CZH30-28	Smaller Washer		
CZH30-29	Bigger Washer		

Ming Yang Reels Model CZH 30

Note: When ordering parts, please add CZH30- to the corresponding part number as identified by diagram.

